



Product Safety Recall



Do you own these products?

Music Box

Novelty music toy containing a button battery, included with Hot Chocolate Design branded shoes.

Dates sold: 30 November 2019 – 8 November 2023



Why the product is recalled: The product does not comply with [the mandatory standards for button/coin batteries](#). The button/coin battery is not adequately secured and are accessible to young children. The product does not include the required warning information.

Hazard: There is a risk of choking, severe internal burn injuries or death to young children if they gain access to the batteries and swallow them or place them inside their bodies. Severe or fatal injuries can happen in 2 hours or less.

Consumers may be unaware that the product contains button batteries.



Consumers should stop using the product immediately and dispose of the music box and battery safely. Store out of reach of children until the music box is disposed of.

Options for safe disposal of the music box include B-cycle, Planet Ark, Battery World, Bunnings and Woolworths.



For more information contact Popping Candy International Pty Ltd on gayle@poppingcandy.com.au or by phone on 0455 049 250. Or visit <https://poppingcandy.com.au/pages/faqs>.



Purchased from:

Beserk, ShoeFun, Miss Goody 2 Shoes and Popping Candy

PRA2023/19980

See productsafety.gov.au for
Australian product recall information